



# MIDWAY FIRE ACADEMY

1322 COLLEGE PKWY, GULF BREEZE, FL 32563  
OFFICE (850)934-4442 [www.midwayfireacademy.com](http://www.midwayfireacademy.com)

---

## STATE PERFORMANCE PRACTICALS

### SCBA EVOLUTION (2:00 MINUTES)

1. Daily check (charge system, then check pressures, PASS, and straps.)
2. Put on full PPE.
3. Candidate verbalizes “SCBA is in service ready condition.”
4. Candidate affirms he/she is ready.
5. Evaluator gives order and time begins.
6. Candidate verbalizes “Bottle pressure \_\_\_\_\_ psi.”
7. Candidate puts on SCBA using coat method. (Leave on helmet and gloves.)
8. Proceed to tool area and pick up specified tool carrying it correctly to entry point.
9. Kneel down and take off helmet and gloves.
10. Don mask, lower straps first, then top.
11. Perform 2 second seal check:
  - A. MSA- Put palm over inlet hole, inhale forcing mask to face, leave palm on and exhale. Verbalize “exhalation valve working.” Then turn on bottle completely.
  - B. Scott- Plug in, inhale forcing the mask to the face, then exhale. Verbalize “Exhalation valve working.” Then turn on bottle completely.
  - C. ISI- Flip AirSwitch to SCBA, then inhale forcing the mask to the face, then exhale. Verbalize “Exhalation valve working.” Then turn on bottle completely.
12. Verbalize “Low pressure alarm working, PASS device activated, and remote pressure reads \_\_\_\_\_ psi.”
13. MSA- Plug in at this time.
14. Roll up Nomex hood, put on helmet, then put on gloves.
15. Verbalize over radio “Candidate \_\_\_\_\_, making entry PAR 1.”
16. Grab tool and crawl around cone and back.

17. Time stops when candidate clears the entry point.
18. Verbalize over the radio "Candidate \_\_\_\_\_, clear of structure PAR 1."
19. Leave tool and stand up w/ arms out.
20. Candidate will be inspected.
21. Come off air and doff mask, top straps first, then lower.
22. Fully loosen straps, and secure mask.
23. Put PPE back on and advance to next station.